

2-phase-descaling tablets

Descaling tablets for JURA fully automatic coffee machines

UFI: 6250-10GK-U00A-V32V

Mode of action

Descaling tablets especially developed for JURA fully automatic coffee machines based on organic and inorganic acids for thorough removal of debris and calcium deposits. The formulation is tailored to use in JURA fully automatic coffee machines and ensures effective while gentle descaling, thereby extending the life of your coffee machine. They can also be used in all other areas, as in kettles, boilers, etc where calcium deposits must be removed.

Properties

Tablet, square, top blue, bottom white
Neutral odour
Height: 8,2 - 8,8 mm
Width: 36 mm
Weight: 17 ± 0,5 g
Soluble in water.
Dissolution time (0.5 l/30 °C): < 5 min

Ingredients

(according to regulation (EC) No 648/2004)
MALEIC ACID
SULFAMIC ACID
SODIUM BICARBONATE
BENZOTRIAZOLE
COLORANT

For more information on the ingredients please click [here](#).

Instructions for use

1. In a container, dissolve the content of one blister pack (3 tablets) in the volume of water specified below. Note: Use lukewarm water (max. 40 °C) to ensure it dissolves rapidly.
2. Start the descaling operation as described in the instructions for use.
3. Pour the mixture into the water tank at the time specified in the instructions for use.
4. The rest of the procedure is described in the instructions for use.

Mixing ratio: IMPRESSA C, E, F, J class: 0.5 l, all other IMPRESSAs: 0.6 l, SUBITO: 0.7 l, JAGUA S60: 0.4 l, JAGUA D70: 0.3 l

Packing units

Folding box of 3 x 3 tablets, jar of 36 tablets, bucket of 120 tablets.

Article No.

61848, 62081, 62084, 64309, 70699, 70751

Toxicological and ecological information

The product is classified as irritant, i. e., short, frequently or prolonged contact with skin or mucous membrane may cause inflammations. Danger of serious damage to health by prolonged exposure if swallowed.

The operation of public sewage treatments plants is not affected even if the descaling solution is added in larger amounts. The product complies with the biodegradability criteria as laid down in Regulation (EC) No 648/2004 on detergents.

Handling, storage and disposal considerations

Keep container tightly closed, protect against humidity, water and heat.

Waste code product: 20 01 29

Residues of the product can be disposed of in the normal drainage system.

Hazards identification

Warning

H302: Harmful if swallowed.

H315: Causes skin irritation.

H317: May cause an allergic skin reaction.

H319: Causes serious eye irritation.

H335: May cause respiratory irritation.

H412: Harmful to aquatic life with long lasting effects.

P102: Keep out of reach of children.

P264: Wash hands thoroughly after handling.

P301+P312: IF SWALLOWED: Call a POISON CENTER/ doctor if you feel unwell.

P305+P351+P338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

P337+P313: If eye irritation persists: Get medical advice/attention.

P501: Dispose of contents/container in accordance with local regulations.

First aid measures

In case of accident or if you feel unwell, seek medical advice immediately (show directions for use or safety data sheet if possible). Change **contaminated, saturated clothing** immediately.

If the tablet, tablet dust or the descaling solution get into contact with the **eyes**, flush immediately with plenty of flowing water for 10 to 15 minutes holding eyelids apart and consult an ophthalmologist.

If the tablet, tablet dust or the descaling solution is **swallowed**, rinse the mouth immediately and drink plenty of water. Do not induce vomiting. Seek medical advice if you feel unwell.

If the descaling solution gets into contact with the **skin**, wash immediately with plenty of water.

JURA Elektroapparate AG
Kaffeeweltstraße 10
CH-4626 Niederbuchsiten
Tel.: +41 (0) 62 389 82 33
jura.com

JURA Elektrogeräte Vertriebs-GmbH
Postfach 99 01 44
D-90268 Nürnberg
Tel.: +49 (0) 911 25 25 0
de.jura.com

JURA Gastro Vertriebs-GmbH
An der Zugspitze 1
D-82491 Grainau
Tel.: +49 (0) 8821 966 73 0
juragastroworld.de